

I'm not a bot





































Dealing with a Samsung VRT washer that isn't working? You're not alone. Many users face issues with these machines, but most problems have simple solutions. Understanding your Samsung VRT washer's common problems can save you time and money. From strange noises to error codes, these issues might seem daunting. But, with a little guidance, you can troubleshoot most of them yourself. This blog will walk you through easy fixes and tips to keep your washer running smoothly. Whether it's a minor glitch or a more serious problem, knowing what to look for can make all the difference. Let's dive into the world of Samsung VRT washer troubleshooting and get your machine back on track. Credit: [www.samsung.com](http://www.samsung.com) Samsung VRT washers are popular for their efficiency and advanced features. But like any appliance, they can have problems. Common issues can disrupt daily routines. This section covers frequent problems and their solutions.No PowerIf your Samsung VRT washer has no power, check the basics first. Make sure it's plugged in. Check the circuit breaker. Sometimes, the power cord may be damaged. Inspect it for any signs of wear. If the washer still doesn't turn on, there might be an internal issue. In such cases, professional help is needed.Water LeaksWater leaks can cause a big mess. First, check the hoses. They might be loose or cracked. Tighten or replace them as needed. Also, inspect the door seal. A worn-out seal can cause leaks. Clean the seal regularly to prevent buildup. If the problem persists, the washer's internal parts may be faulty.Unusual NoisesUnusual noises can be alarming. Often, they are due to an unbalanced load. Make sure clothes are evenly distributed. Loose objects like coins can also cause noise. Remove any foreign items from the drum. If the noise continues, there might be a mechanical problem. In that case, a technician should check the washer. Credit: [www.youtube.com](http://www.youtube.com) Understanding the error codes on your Samsung VRT Washer is crucial. These codes help identify issues, so you can fix them promptly. They save time and reduce frustration. Understanding Error Codes Error codes appear on the washer's display screen. Each code represents a specific problem. Knowing their meanings helps in troubleshooting. This knowledge empowers you to act fast. Common errors include water supply issues, drainage problems, and sensor malfunctions. Some errors are easy to fix. Others may need professional help. Common Error Codes Here are some common error codes you may encounter. 1E: This code indicates a water level sensor issue. Check the sensor and connections. Ensure there is no blockage. 3E: This error points to a motor problem. The motor may be overloaded. Reduce the load and try again. 4E: This code signals a water supply issue. Check the water taps and hoses. Make sure they are open and connected. 5E: This error indicates a drainage problem. Check the drain hose and filter. Clear any blockages. UE: This code shows an unbalanced load. Redistribute clothes in the drum. Ensure they are evenly spread. OE: This error means the washer is overflowing. Check the water level sensor and hose connections. LE: This code signals a door lock issue. Ensure the door is closed properly. Check the latch and sensor. Understanding these codes helps maintain your washer. It ensures efficient and smooth operation. Regular maintenance of your Samsung VRT washer ensures it runs smoothly. It helps prevent common problems and extends the life of your appliance. Here are some basic maintenance steps to keep your washer in top condition.Cleaning The FilterThe filter in your Samsung VRT washer collects debris and lint. Over time, it can get clogged. To clean the filter, locate it at the bottom front of the machine. Open the cover and remove the filter. Rinse it under running water to remove any buildup. Reinsert the filter and close the cover.Checking The HosesInspect the hoses of your washer regularly. Look for any signs of wear or damage. Ensure there are no leaks or cracks. Tighten the connections if needed. Replace any damaged hoses to avoid water leaks. Proper hose maintenance prevents flooding and ensures efficient water flow. Drum problems are common in Samsung VRT washers. They can lead to loud noises, shaking, and even damage to clothes. Fixing these issues ensures a smooth and efficient wash cycle. Let's explore two critical aspects: balancing the load and removing stuck items. Balancing The Load A balanced load is crucial for the smooth operation of your washer. An unbalanced load can cause the drum to wobble. This leads to loud noises and potential damage. Distribute clothes evenly in the drum. Mix large and small items for better balance. Avoid overloading the washer. Use the correct wash cycle for the type of clothes. Proper load distribution helps in maintaining the washer's efficiency. It also extends the life of your machine. Removing Stuck Items Sometimes, items get stuck in the drum. This can cause noise and even damage the washer. Follow these steps to remove stuck items: Turn off the washer and unplug it. Check the drum for any visible obstructions. Use a flashlight to look inside the drum. Gently remove any stuck items. Inspect the drum for any signs of damage. Removing stuck items ensures the drum operates smoothly. It also prevents damage to your clothes and washer. Spin cycle issues can disrupt your laundry routine. Samsung VRT washers are designed for efficient and quiet washing. But sometimes, the spin cycle doesn't work as expected. This can be frustrating. Let's explore common problems and their solutions.Improving Spin PerformanceBalance the load inside the washer. Uneven loads cause the washer to shake. This can affect the spin cycle. Distribute clothes evenly around the drum. Avoid overloading the washer. Too many clothes can hinder the spin.Check the washer's leveling. An unlevel washer can cause spin issues. Adjust the feet to ensure the washer sits evenly on the floor. Proper leveling helps the spin cycle work smoothly.Resolving Spin ErrorsEnsure the door is closed properly. A partially closed door can prevent spinning. Listen for the click when closing the door. This ensures it is secure.Check for error codes on the display. These codes indicate specific problems. Refer to the user manual for code meanings. This can help you identify the issue quickly.Inspect the drain hose for kinks. A blocked hose can stop the spin cycle. Straighten any kinks to restore proper drainage. This can resolve many spin cycle issues.If these steps do not help, consider calling a technician. There might be a deeper issue. Professional help ensures your washer works correctly. The Samsung Vrt Washer is known for its efficiency. Yet, sometimes, users face issues with water temperature. This section covers common water temperature problems and their solutions. Let's dive into the details. Hot Water Issues If your Samsung Vrt Washer isn't getting hot water, there could be several reasons. Here are some common causes and solutions: Check the water heater: Ensure your water heater is working properly. The washer relies on it for hot water. Inspect the hoses: Make sure the hot water hose is connected correctly. Examine the inlet valve: The inlet valve might be clogged or faulty. Clean or replace it if needed. Temperature settings: Verify the wash cycle settings. Some cycles do not use hot water. If none of these steps work, it might be time to call a professional. A technician can diagnose and fix internal issues. Cold Water Problems Cold water problems can be frustrating. Here are some tips to troubleshoot cold water issues: Water supply: Ensure the cold water supply is turned on and flowing. Hoses and filters: Check for clogs in the cold water hose and filters. Clean them if necessary. Inlet valve: Similar to hot water issues, the inlet valve might be the culprit. Inspect and clean it. Cycle settings: Confirm that the selected cycle uses cold water. Adjust if needed. Sometimes, a simple reset can solve the issue. Unplug the washer for a few minutes, then plug it back in. This can reset the machine's control board. If the problem persists, consult the washer's manual or contact customer support for further assistance. Experiencing problems with your Samsung Vrt Washer's detergent dispenser? You're not alone. Many users face issues that can disrupt washing routines. Understanding these issues and learning how to address them can save time and frustration.Cleaning The DispenserFirst, remove the detergent dispenser from the washer. Check for any detergent buildup or residue. Use warm water and a soft brush to scrub the dispenser. Ensure all compartments are thoroughly cleaned. Dry the dispenser before placing it back.Fixing Dispenser BlockagesBlockages are common in detergent dispensers. Inspect the dispenser for any clogs. If you find any, use a cloth or brush to clear them. A mixture of water and vinegar can help dissolve stubborn blockages. Rinse the dispenser well after cleaning. Is your Samsung Vrt Washer acting up? Advanced troubleshooting can help solve complex problems. This guide covers resetting your washer and contacting support for persistent problems.Resetting The WasherResetting your Samsung VRT washer can fix many issues. Unplug the washer from the power source. Wait for 10 minutes. Plug it back in. Press and hold the Start/Pause button for 10 seconds. Release the button and restart the wash cycle. This can often solve software malfunctions. Contacting SupportIf resetting doesn't work, it may be time to contact support. Samsung has a dedicated customer service team. They can help diagnose and fix issues. Have your washer's model number ready. Describe the problem in detail. This information helps the support team provide accurate solutions. You can reach them via phone or online chat. They might suggest a technician visit if needed. Credit: [www.thespecious.com](http://www.thespecious.com) Check if the load is balanced. Also, ensure the lid is fully closed. Unplug the washer for 5 minutes. Then, plug it back in and start a new cycle. Check for loose objects in the drum. Also, ensure the washer is level on the floor. The "nd" error means the washer is not draining properly. Check the drain hose and filter. Ensure the washer is on a flat surface. Also, avoid overloading the washer with heavy items. Fixing your Samsung VRT washer can be simple. Follow the troubleshooting steps provided. Always check for common issues first. Clean filters, check hoses, and inspect connections. Regular maintenance keeps your washer running smoothly. If problems persist, consult a professional technician. Understanding your washer helps prevent future issues. Maintain it well for long-lasting performance. Enjoy hassle-free laundry days ahead. In today's fast-paced world, having a reliable washing machine is crucial. The Samsung VRT (Vibration Reduction Technology) Steam Washer is renowned for its innovative features and performance. However, like any appliance, it may experience occasional glitches or operational issues, necessitating a reset. This article will guide you through resetting your Samsung VRT Steam Washer, ensuring you can continue enjoying its benefits without any hassle. Understanding the Need for a Reset Resetting your Samsung VRT Steam Washer can resolve various problems, from minor glitches to operational faults. Common scenarios that may prompt a need for a reset include: Unresponsive Controls: Sometimes, the washer may not respond to button presses or selections. Error Codes: If an error code appears on the display, a reset may be required to clear it. Power Source Issues: Occasionally, the washer may not power on, possibly due to a power outage or a tripped circuit breaker. To ensure a successful reset, follow these steps: 1. Preparation: Before beginning the reset process, it's essential to prepare adequately. Follow these steps to ensure a successful reset: 1. Review the User Manual: Review the user manual for specific instructions regarding the reset process. 2. Gather Necessary Information: Take note of any error codes displayed on your washer. This will be helpful should troubleshooting be necessary after the reset process. Additionally, check your washer's model number, typically found on a sticker inside the door frame, which may be useful in locating specific troubleshooting resources or support. How to Perform a Reset on Your Samsung VRT Steam Washer Resetting the Samsung VRT Steam Washer can be accomplished in a few straightforward steps. Here's a detailed look at two primary methods: Method 1: Soft Reset A soft reset can help resolve minor issues without erasing your settings or data. Steps for Performing a Soft Reset: Power Off the Washer: Disconnect the power supply by unplugging the washer or turning off the circuit breaker. Wait for 10-15 Minutes: Allow the washer to remain powered down for the specified duration. This pause gives the internal components a chance to discharge and recalibrate. Reconnect the Power: Plug the washer back into the power source or turn the circuit breaker back on. Check for Functionality: Once powered back on, check if the washer operates normally. If the issues persist, consider trying a hard reset. Method 2: Hard Reset In more severe cases where a soft reset doesn't work, a hard reset may be necessary. This method usually resolves persistent issues such as unresponsive controls and consistent error codes. Steps for Performing a Hard Reset: Disconnect the Power: As with the soft reset, unplug your washer from the wall outlet or switch off the circuit breaker. Press and Hold the Start/Pause Button: While the machine is unplugged, press and hold the Start/Pause button for about 5-10 seconds. Reconnect the Power: After holding the button, plug the washer back in or turn the circuit breaker on. Release the Button: After reconnecting the power, release the Start/Pause button. Run a Test Cycle: Test your washer's functions, including the wash cycle, to verify if the reset resolved the issue. What to Do If the Reset Doesn't Work If your Samsung Vrt Steam Washer remains unresponsive or continues to display error codes after the reset, follow these troubleshooting steps: 1. Inspect for Physical Issues Check if there are any visible problems with your washer: Door Lock: Ensure the door is securely closed. A malfunctioning door lock may prevent the washer from operating. Hoses: Inspect the water hoses for kinks or blockages that could impede water flow. 2. Vibration and Leveling Ensure your washer is situated on a level surface. An unbalanced washer can lead to vibration issues, triggering error codes. Adjust the legs of the washer to stabilize it if necessary. 3. Contact Customer Support If you have tried all the above steps without resolution, contacting Samsung Customer Support may be the best next course of action. Have your model number, error codes (if applicable), and a detailed description of the problem handy for quicker assistance. Preventive Maintenance Tips Regular maintenance can help prevent the need for a reset in the first place. Here are some guidelines to keep your Samsung VRT Steam Washer running smoothly: 1. Regular Cleaning Regularly clean the washer, including the drum, detergent drawer, and door seal. This practice helps prevent mold and mildew buildup, ensuring optimal performance. 2. Use the Right Detergent Always use a high-efficiency (HE) detergent as recommended by Samsung. Using the wrong type of detergent can cause sudsing issues and performance problems. 3. Balance Loads To avoid excessive vibration, always ensure your laundry loads are balanced. Mixing heavy and light items can lead to an unbalanced wash cycle. Conclusion A malfunctioning Samsung VRT Steam Washer can be frustrating, but by understanding how to reset it effectively, you can handle most issues with ease. Whether you opt for a soft reset or a hard reset, following the outlined steps ensures you will be back to enjoying clean clothes in no time. Remember to keep your washer well-maintained to minimize the chances of encountering problems in the first place. If issues persist despite following all troubleshooting methods, do not hesitate to contact Samsung support for professional assistance. By keeping this guide handy, you'll have the information you need at your fingertips whenever necessary. What is the purpose of resetting a Samsung VRT Steam Washer? Resetting your Samsung VRT Steam Washer can help resolve various issues, including unresponsive controls, error codes, and persistent problems. It's a useful troubleshooting step when encountering specific cycles that aren't completing correctly or when the washer seems to be stuck in a particular mode. It can clear temporary glitches and improve the washer's overall functioning. How do I reset my Samsung VRT Steam Washer? To reset your Samsung VRT Steam Washer, first, unplug the machine from the power source. Wait for about 5 to 10 minutes to allow any residual charge to dissipate. This step ensures that the washer's internal memory is cleared, which is essential for a successful reset. After waiting, plug the washer back into the outlet and turn it on. Most Samsung washers can also be reset by pressing and holding the "Start/Pause" button for about 5 seconds, but the method may vary slightly depending on your model, so refer to your user manual for specific instructions if needed. What should I do if the reset doesn't solve the problem? If resetting your Samsung VRT Steam Washer does not resolve the issue, it may indicate a more serious underlying problem. Check for common issues such as clogged hoses, blocked filters, or door latch problems, as any of these can affect performance. Ensure that all connections are secure and that the washer is level to avoid any operational glitches. If you have ruled out these common problems and the issue persists, it may be time to contact Samsung customer service or a qualified technician for assistance. They can provide further diagnostics or recommend repairs based on the symptoms you're experiencing. Will resetting my washer erase my settings? No, resetting your Samsung VRT Steam Washer typically does not erase your saved settings or favorite cycles. A reset is mainly focused on clearing temporary errors and refreshing the system. However, certain settings may return to their factory defaults after a reset, depending on what specific issues are being resolved. For example, if you have customized settings like a good practice to write down any specific cycle adjustments you've made. This way, you can easily restore them if necessary after the reset. Can I reset my washer remotely? Yes, you can reset your washer remotely using the Samsung SmartThings technology or similar smart home applications, if you may have the option to reset the appliance remotely. Through the app, you can access various features, including control over cycles and appliance functions, which might allow you to reset the washer without being physically present. However, not all models support this feature. It's essential to refer to your user manual or the Samsung SmartThings app for instructions specific to your model to determine whether remote reset options are available. What error codes indicate that I need to reset my washer? Several error codes may signal that a reset is needed for your Samsung VRT Steam Washer. Common codes include "ND" for draining issues, "UE" for unbalanced load errors, or other errors that prevent the machine from completing a cycle. When these codes appear, a reset can often clear them and allow normal operation to resume. If after resetting the error codes persist, it is crucial to troubleshoot further. This may involve inspecting hoses, checking the load balance, or examining the door seal to ensure everything is functioning as it should. If issues continue, seeking professional help might be necessary. Ensure the washer is empty, unplugged, and placed on a level, stable surface. Turn the dial to select the "Calibration" mode (may vary depending on the washer model). Samsung's VRT (Vibration Reduction Technology) washers are renowned for their exceptional performance and efficiency. However, to maintain optimal cleaning results and prevent excessive noise or vibrations, regular calibration is crucial. This guide will provide you with a step-by-step process on how to calibrate your Samsung VRT washer effortlessly. Understanding the Need for Calibration Calibration aligns the washer's internal components, ensuring proper weight distribution and balance during the wash cycle. Over time, components may shift slightly, leading to imbalances that can cause excessive noise, vibrations, and reduced cleaning efficiency. Regular calibration helps rectify these issues, extending the lifespan of your washer. Step-by-Step Calibration Process Materials Required: Empty bucket or container Measuring cup Towels or rag Instructions: 1. Prepare the Washer: Ensure the washer is empty, unplugged, and placed on a level, stable surface. 2. Fill the Bucket: Fill the bucket with 4 cups of water. 3. Insert the Bucket: Open the washer door and place the bucket inside the drum. Position it in the center, ensuring it remains upright. 4. Close the Door: Securely close the washer door. 5. Plug in the Washer: Connect the washer to a power source. 6. Enter Calibration Mode: Turn the dial to select the "Calibration" mode (may vary depending on the washer model). 7. Start Calibration: Press the "Start" button to initiate the calibration process. The washer will automatically adjust the internal components to ensure proper balance. 8. Complete the Cycle: The calibration process typically takes a few minutes. Once complete, the washer will display a "Calibration Complete" message. 9. Unplug the Washer: Disconnect the washer from the power source. 10. Remove the Bucket: Open the washer door and carefully remove the bucket. Troubleshooting Common Calibration Issues Issue: Washer does not enter Calibration Mode. Solution: Check if the washer is empty and the door is properly closed. Unplug the washer and wait a few minutes before attempting to enter Calibration Mode again. Issue: Excessive noise or vibrations during calibration. Solution: Ensure the bucket is positioned correctly and remains upright throughout the calibration process. If the issue persists, contact a qualified technician. Additional Tips for Optimal Performance Calibrate your washer regularly, at least every 6 months or after any major maintenance or repairs. Use the correct amount of detergent and avoid overloading the washer. Level the washer's legs to ensure stability on an even surface. Clean the washer drum and drain pump regularly to prevent buildup and potential imbalances. Beyond Calibration: Maintaining Your Samsung VRT Washer Besides calibration, regular maintenance is essential to keep your Samsung VRT washer running smoothly. Here are some additional tips: Regularly clean the detergent drawer and the filter. Use a washing machine cleaner to remove any detergent deposits and buildup from the drum and hoses. Check and clean the filter after each wash cycle. Inspect the water hoses and the door seal for signs of wear or damage. Common Questions and Answers Q: How often should I calibrate my Samsung VRT washer? A: It is recommended to calibrate your washer every 6 months or after any major maintenance or repairs. Q: Can I calibrate my washer without a bucket? A: No, a bucket or container is necessary to create the required weight distribution during calibration. Q: What happens if I do not calibrate my washer regularly? A: Lack of calibration can lead to excessive noise, vibrations, reduced cleaning efficiency, and potential damage to the washer's components. Was this page helpful?YesNo Thanks for your feedback! 592-49079-0 WF350AN WF340AN Washer user manual imagine the possibilities Thank you for purchasing this Samsung product. To receive more complete service, please register your product at [www.samsung.com/register](http://www.samsung.com/register) WF350AN-02833B EN.indd 1 2010-04-06 JAAU 10:07:54... 2. Super capacity Samsung's extra-large capacity laundry machine can wash a full set of your bedding, a king-size comforter, or up to 26 bath towels in a single load. Since you don't have to do as many loads, you save time, money, water and energy. It also offers a built-in storage drawer that can hold a 100oz.(6.25 lb) bottle of detergent. 12. Stacking (Model No: SK-3AI/XAC, SK-4A/XAC, SK-5A/XAC) Samsung's washers and dryers can be stacked to maximize usable space. An optional stacking kit is available for purchase from your Samsung retailer. Congratulations on your new Samsung washer. This manual contains important information on the installation, use and care of your appliance. Please take time to read this manual to take full advantage of your washer's many benefits and features. Page 5 WARNING: To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following: WARNING 1. Read all instructions before using the appliance. 2. Do not wash or dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, other flammable or explosive substances as they give off vapors that could ignite or explode. Page 6 safety information: SEVERE WARNING SIGNS FOR INSTALLATION WARNING Plug the washer into a AC 120V/60 Hz/15A wall socket or higher and use the correct power cord. Never use an extension cord. WARNING GROUNDING ELECTRICAL GROUNDING IS REQUIRED ON THIS APPLIANCE. setting up your washer Drain facility The recommended height of the standpipe is 18 in (46 cm). The drain hose must be routed through the drain hose clip to the standpipe. The standpipe must be large enough to accept the outside diameter of the drain hose. STEP 2 Removing the shipping bolts before using your washer, you must remove the four shipping bolts from the back of the unit. 1. Loosen all the bolts with the supplied wrench. 2. Slide the bolt and spacer up and remove the bolt with the spacer through the hole in the rear wall of your washer. Page 16 setting up your washer 3. Check the inlet hose to ensure a washer is inside each fill hose. Cold Thread the inlet hoses to the HOT and COLD faucet connections. On the other end of the hose, check for one rubber washer per hose and install each fill hose to the water valve. washing a load of laundry LOADING YOUR WASHER • You can fill the tub with dry, unfolded clothes; but DO NOT OVERLOAD the tub. • Overloading may reduce washing efficiency, cause excess wear, and possibly cause creasing or wrinkling of the load. "... washing a load of laundry OVERVIEW OF THE CONTROL PANEL WF350\* WF340\* Select the appropriate cycle for the type of load. This will determine the tumble pattern and spin speed for the cycle. To minimize wrinkling of your laundry, select the Perm Press cycle. Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 19 Quick Wash - For lightly soiled garments needed quickly. Rinse + Spin - Use for loads that need rinsing only or to add rinse-aided fabric softener to a load. Digital graphic Displays the remaining cycle time, all cycle information, and error messages; display Press the button repeatedly to cycle through the different water temperature options, washing a load of laundry Child Lock This function prevents children from playing with your washer. Activating the Child Lock function Press and hold both the Spin and Soil Level buttons simultaneously for approximately 3 seconds. • If the Child Lock function is activated, the door is locked and the "Child Lock" indicator light will glow. Page 20 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7864 (1-800-SAMSUNG) 32. cycle chart WF350AN-02833B EN.indd 32 2010-04-06 JAAU 10:08:08... Page 33 appendix FABRIC CARE CHART The following symbols provide garment care direction. The clothing care labels include symbols for washing, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems. Page 34 appendix HELPING THE ENVIRONMENT • Your washer is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance. Page 35 CYCLE CHART Use this chart to set the best cycle and option for you laundry. ( : factory setting; : selectable) WF350\* WF340\* Functions Temp Spin Soil Level Normal - For most fabrics including cottons, linens, and normally soiled garments. Page 37 Troubleshooting and information: CHECK THESE POINTS IF YOUR WASHER... PROBLEM SOLUTION If your washer... Make sure the door is firmly closed. • Make sure your washer is plugged in. • Make sure the water source faucets are open. • ... Page 30 troubleshooting and information codes PROBLEM SOLUTION • Fills with the wrong Turn both faucets on fully. • temperature water. Make sure the temperature selection is correct. • Make sure the hoses are connected to the correct faucets. Flush water lines. • ... INFORMATION CODES Information codes may be displayed to help you better understand what is occurring with your washer. CODE SYMBOL MEANING SOLUTION Unbalanced load prevented you Redistribute the load, press the Start/Pause washer from spinning. button. Door is unlocked when washer is Press the Power button to turn off your washer, running. Page 32 Then, the unit SUDs will go back to the operation. When it finishes washing, "End" and "SUDs" codes will blink in turn. For any codes not listed above, call 1-800-726-7